# Glove reference

ScanFlexTect 27 / 40

# Available sizes

(according to EN ISO 21420:2020) 10/XL (one size)

Size	Hand Length (mm)	Hand perimeter (mm)
10/XL	204	254

# **Glove description**

Red PVC double dipped chemical resistant gloves.

The gloves referred to in these instructions, complies with essential requirements of the EU Regulation 2016/425 concerning Personal Protective Equipment (PPE) and belong to Category III. EU type examination performed by:

#### SGS Fimko Ltd, N.B. 0598 **Takomotie 8** FI-00380 Helsinki - Finland

Annual follow-up inspection. Module C2, conducted by:

#### SGS Fimko Ltd, N.B. 0598 **Takomotie 8** FI-00380 Helsinki - Finland

The EU Declaration of Conformity (DOC) can be found at the Scandia Gear website (www.scandiagear.com), under the Scandia product name ScanFlexTect 27 or ScanFlexTect 40 and through the link "Declaration of Conformity".

Read this information carefully before first wear and keep it for future reference.

# Applicable standards

These gloves meet the requirements of the standard EN ISO 21420:2020 "General requirement for protective gloves". Dexterity: level 5.

They have been designed for the following applications:

#### EN 388:2016 Mechanical hazard +A1:2018

4131X



This Standard specifies test methods and performance requirements for gloves which offer protection against mechanical hazards of abrasion, blade cut, tear and puncture.

Levels of performance (of which 4/5 is the highest achievable level):

Abrasion resistance (level1-4) : Level 4

LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4
100 cycles	500 cycles	2000 cycles	8000 cycles

# Blade cut resistance (level 1-5): Level 1

Scandia<sup>®</sup>

LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4	LEVEL 5
1,2	2,5	5,0	10,0	20,0

# Tear resistance (level 1-4) · Level 3

LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4
10 N	25 N	50 N	75 N

#### Puncture resistance (level 1-4) : Level 1

LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4
20 N	60 N	100 N	150 N

TDM: not tested

LEVEL A	LEVEL B	LEVEL C	LEVEL D	LEVEL E	LEVEL F
2 N	5 N	10 N	15 N	22 N	30 N

Resistance to cutting by sharp objects EN ISO13997 (level A-F) X1

 $^{1}$  : An  $\boldsymbol{X}$  as result indicating that the glove was not tested against this type of protection.

# EN ISO 374-1 Chemical hazard - EN ISO 374-1:2016



This standard specifies test methods and performance requirements for gloves which offer protection against dangerous chemicals and micro-organisms.

The gloves are classified in three types according to the resistance to permeation (EN 374-2:2014):

Type A	Penetration time > or = 30 minutes for at least 6 products from the list below
Type B	Penetration time > or = 30 minutes for at least 3 products from the list below
Type C	Penetration time > or = 10 minutes for at least 1 product from the list below

The Type B pictogram is accompanied by a 3-digit code. This code refers to 3 chemicals (from the list of 18 defined chemicals). for which a breakthrough time of at least 30 minutes has been recorded.

А	Methanol	67-56-1	Primary alcohol
В	Acetone	67-64-1	Ketone
с	Acetonitrile	75-05-8	Nitrile Compound
D	Dichloromethane	75-09-2	Chlorinated paraffin
E	Carbon disulphide	75-15-0	Sulphur containing organic compound
F	Toluen	108-88-3	Aromatic hydrocarbon
G	Toluen	108-88-3	Aromatic hydrocarbon
н	Tetrahydrofuran	109-99-9	Heterocyclic and ethereal compound



🛞 Made with 100% recycled paper

Lorentzweg 31 - 3208 LJ Spijkenisse - The Netherlands **T**+31 (0)181 600 955 F +31 (0)181 600 966 E info@scandiagear.com I www.scandiagear.com

**MARITIME** OUTFITTERS since 1974

# SCAN**FLEXTECT** 27 / 40 User Instruction

Т	Ethyl acetate	141-78-6	Ester
J	n-Heptan	142-85-5	Saturated hydrocarbon
к	Sodium hydroxide 40%	1310-73-2	Inorganic base
L	Sulphuric acid 96%	7664-93-9	Inorganic mineral acid
м	Nitric acid 65%	697-37-2	Inorganic mineral acid, oxidizing
Ν	Acetic acid 99%	64-19-7	Organic acid
0	Ammonia 25%	1336-21-6	Organic base
Ρ	Hydrogene peroxide 30%	7722-84-1	Peroxide
Q	Hydrogene fluoride 40%	7664-39-3	Inorganic mineral acid, contact
R	Formaldehyde 37%	50-00-0	Aldehyde

# Performance level in accordance with EN ISO 374-1

Measured break through time (min)	Permeation performance level	Performance level ScanFlecTect
>10	1	
>30	2	
>60	3	Methanol – code A
>120	4	
>240	5	H2S04 – code L
>480	6	NaOH – code K

Note: The information listed above does not reflect the actual duration of protection at the workplace due to other factors influencing the performance such as temperature, abrasion, degradation, etc.

# Performance level in accordance with EN ISO 374-4:2013 Resistance to degration by chemicals

Chemical	Degration mean	Degration standard deviation
Methanol - code A	- 0,3 %	12,0 %
NaOH – code K	- 1,9 %	6,5 %
H2S04 - code L	3,6 %	6,1 %

# EN ISO 374-5

This standard specifies test methods and performance requirements for gloves which offer protection against viruses, bacteria and fungi.

"Not Tested against viruses"

# **Protection limit**

- Scandia's protection warranty applies only to the risks and hazards mentioned in this document.
- Protection against risks or hazards not mentioned in this document is therefore unwarranted. The levels of performance mentioned are valid for the palms and cuffs of the gloves and gloves that are new, unwashed, and in their original condition (i.e., have not been repaired).
- These levels of performance were achieved from tests done according to conditions defined by the applicable standards.
- For gloves that have multiple layers of material, performance levels are guaranteed for the whole glove, not for individual layers.
- To decrease the risk of injury, gloves should not be worn around or when operating machines with moving parts.
- These gloves should be kept away from fire.
- It is recommended to check that the gloves are suitable for the intended use because the conditions at the workplace may differ from the type test depending on temperature, abrasion and degradation.
- When used protective gloves may provide less resistance to the dangerous chemical due to changes in the physical properties. Movements, snag, rubbing, degradation caused by the chemical contact etc. may reduce the actual use time significantly. For corrosive chemicals, degradation can be the most important factor to consider in selection of chemical resistant gloves.
- The chemical resistance has been assessed under laboratory conditions from samples taken from the palm only (except in cases where the glove is equal to or over 400mm -where the cuff is tested also) and relates only to the chemical tested. It can be different if the chemical is used in a mixture.
- Before usage inspect the gloves for any defect or imperfections.

# Storage and cleaning

Gloves should be stored in their original packaging and away from heat, cold, and humidity. Gloves must also be kept in areas that are clean and well ventilated.

# Explanation of the symbols

X	Do not wash
$\bigotimes$	Do not bleach
図	Do not tumble dry
X	Do not iron
X	Do not dry clean

#### Disclaimer

Scandia Gear is not liable for damages that result from improper use of these products.

20231102V13



🛞 Made with 100% recycled paper

Scandia® MARITIME OUTFITTERS since 1974

Lorentzweg 31 - 3208 LJ Spijkenisse - The Netherlands T +31 (0)181 600 955 F +31 (0)181 600 966 E info@scandiagear.com I www.scandiagear.com